

PRINTING INDUSTRY



Cell-Kleen HD2 is a viscous cleaner designed to deep clean water- and solvent-based inks from anilox rolls.

Because of its thixotropic properties, **Cell-Kleen HD2** can be applied either on press or off and will allow for increased dwell time on the roll without dripping down onto other sensitive press components.

Cell-Kleen HD2 will penetrate deeply into the cells and clean them like never before. By using **Cell-Kleen HD2** to routinely clean anilox rolls, the frequency with which rolls need to be sent out for reconditioning will be greatly reduced and print quality will be greatly improved.

FEATURES AND BENEFITS

- Clings to vertical surfaces
- Deep cleans
- Effectively removes camouflage
- Economical: 1 gallon cleans up to 10 rolls
- Cost and labor reductions
- Improved print quality
- Extended roll life
- Leaves no film or residue after rinsing

Use procedures

Apply **Cell-Kleen HD2** with a brush or coarse spray and let dwell for 15 to 30 minutes. In a very short time you will see the ink rising to the surface. Some agitation with a stainless steel or brass brush may be required depending on soil conditions. Thoroughly rinse with water, or remove with a clean damp rag if cleaning is being done on press.

Note

Cell-Kleen HD2 should not be used on tin, aluminum or other soft metals.

CELL-KLEEN HD2

DEEP-CLEANING ANILOX ROLL CLEANER

PHYSICAL PROPERTIES

Appearance	Brown/amber viscous liquid
Odor	Mild solvent
pH	>13
Freezing Point	About 25°F
Boiling Point	About 220°F
Flash Point (TCC)	Above 200°F
Relative Density	1.24
Auto-Ignition Temperature	Not determined
Water Solubility	Complete
Viscosity	About 30 CP at room temperature

INCOMPATIBILITY

Strong acids. Soft metals.

WAREHOUSING PRECAUTIONS

Store locked up. Store in corrosive resistant container. Plastic is recommended. Keep container tightly closed when not in use. Do not store in direct sunlight. Avoid storing above 120°F (49°C).

AVAILABLE SIZES

4 x 1 gallon Case

5 gallon Drum

FIRST AID MEASURES

If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a poison center, doctor, physician or other competent medical authority for medical advice. Penetone recommends that after any eye exposure a physician be seen immediately.

If swallowed: Rinse mouth. DO NOT INDUCE VOMITING. Immediately call a poison center, doctor, physician or other competent medical authority for medical advice.

If inhaled: Remove person to fresh air and keep comfortable for breathing. Immediately call a local Poison Control Center, physician, or other competent medical authority for medical advice.

If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. A mild soap may be used to wash skin. Wash contaminated clothing before reuse. Immediately call a local Poison Control Center, doctor, physician or other competent medical authority for medical advice.

PERSONAL PROTECTION Security equipment



WHMIS



IMPORTANT: Before using **CELL-KLEEN HD2**, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).



CARLSTADT

700 Gotham Parkway
Carlstadt, NJ 07072
Tel.: 201-567-3000
Toll free: 1-800-631-1652

MONTREAL

10,900 Secant Street
Anjou, QC H1J 1S5
Tel.: 514-355-4660
Toll free: 1-800-361-8927

EDMONTON

11411-160 Street
Edmonton, Alberta T5M 3T7
Tel.: 780-454-3919
Toll free: 1-866-454-3919

United States
www.penetone.com

Canada
www.westpenetone.com