

PENSOLV L1060

HIGHLY REFINED SOLVENT CLEANER

GENERAL USE



Pensolv L1060 is an excellent product choice for a safer and more pleasant to use cleaning solvent.

Pensolv L1060 is a specially refined solvent where many undesirable characteristics of solvent cleaners are eliminated.

Pensolv L1060 quickly degreases bearings, mill housings, work rolls, motors and any metal part where solvent cleaning is needed.

FEATURES AND BENEFITS

- High 160°F flash point
- Very low odor
- Free of chlorinates
- Dries to negligible residue
- High dielectric breakdown voltage
- Improved safety
- Economical
- More worker comfort
- Excellent for electrical uses

DIRECTIONS FOR USE

Use procedure

For Electrical Cleaning

Pensolv L1060 is a clear solvent which should be used full strength. The preferred method of applying **Pensolv L1060** is by non-atomiz-ing spray. Other application methods include brushing it on or dippingparts in the solvent. After application and a brief soaking period, blowsurfaces dry with compressed air. No water rinsing is required.

All power must be shut off or disconnected and the part thoroughly dried before powering up.

PENSOLV L1060

HIGHLY REFINED SOLVENT CLEANER

PHYSICAL PROPERTIES

Appearance	Clear liquid
Odor	Mild hydrocarbon
рН	Not applicable
Freezing Point	About -34°F
Boiling Point	360-480°F
Flash Point (TCC)	160°F
Relative Density	0.78
Auto-Ignition Temperature	About 400°F
Water Solubility	None
Viscosity	Less than 5 CP at room temperature

INCOMPATIBILITY

Strong oxidizing agents.

WAREHOUSING PRECAUTIONS

Store in a well-ventilated place. Keep container tightly closed. Open slowly in order to control possible pressure release. Keep cool. Store locked up. Do not store near heat, sparks, open flame, or other ignition sources. Do not store in direct sunlight. Avoid storing above 120°F (49°C).

AVAILABLE SIZES

5 gallon Pail

55 gallon Drum

FIRST AID MEASURES

If in eyes: Rinse cautiously with water for several minutes. If contact lenses present, remove them if easy to do. Continue rinsing for several minutes. If eye irritation persists: Get medical advice or attention. Penetone recommends that after any eye exposure and initial treatment a physician be seen immediately.

If swallowed: Immediately call a poison center, doctor, physician or other competent medical authority. Product presents an aspiration hazard. DO NOT INDUCE VOMITING.

If inhaled: Remove person to fresh air and keep comfortable for breathing. Call a poison center, doctor, physician or other competent medical authority if you feel

If on skin: Wash with plenty of water or a mild soap. Take off contaminated clothing and wash it before reuse. If skin irritation occurs: Get medical advice or attention.

PERSONAL PROTECTION Security equipment

















IMPORTANT: Before using PENSOLV L1060, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).



CLIFTON

125 Kingsland Avenue Clifton, NI 07014 Tel.: 201-567-3000

MONTREAL

10,900 Secant Street Anjou, QC H1J 1S5 Tel.: 514-355-4660 Toll free: 1-800-631-1652 Toll free: 1-800-361-8927

FDMONTON

11411-160 Street Edmonton, Alberta T5M 3T7 Tel.: 780-454-3919 Toll free: 1-866-454-3919

United States www.penetone.com

www.westpenetone.com