

MILITARY / COMMERCIAL AVIATION



Pensolv K4HP was developed as a replacement for MEK and exhibits cleaning performance at the same level.

Pensolv K4HP will remove oils, greases, tape residues and other soils typically removed by ketone solvents.

Pensolv K4HP has a closed cup flash point of approximately 40°F. Dry time is immediate.

FEATURES AND BENEFITS

- Free of chlorinates and CFCs
- No residue
- Excellent tape residue remover
- No SARA Title III reportables
- Fast drying
- Drop in MEK replacement

Use procedure Spray **Pensolv K4HP** on cloth and wipe on part.

Note Electrical equipment should be off or not operating when cleaning. Do not restart equipment until thoroughly dry. Test on plastics and elastomers before use. Use this product with adequate ventilation.

PENSOLV K4HP

WIPE SOLVENT CLEANER

PHYSICAL PROPERTIES

Appearance	Clear liquid
Odor	Sweet
pH	Not applicable
Freezing Point	Less than 0°F
Boiling Point	About 215°F
Flash Point (TCC)	40°F
Relative Density	0.78
Auto-Ignition Temperature	Not determined
Water Solubility	Complete
Viscosity	Less than 5 CP at room temperature

INCOMPATIBILITY

Strong oxidizing agents.

WAREHOUSING PRECAUTIONS

Store in a well-ventilated place. Keep container tightly closed. Keep cool. Store locked up. Do not store near heat, sparks, open flame, or other ignition sources. Do not store in direct sunlight. Avoid storing above 120°F (49°C).

AVAILABLE SIZES

5 gallon Pail

APPROVALS

Grumman GS115VR1

Boeing BAC 5750

FIRST AID MEASURES

If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists or develops: Get medical advice or attention. Penetone recommends that after any eye exposure a physician be seen immediately.

If swallowed: Immediately call a poison center, doctor, physician or other competent medical authority. Rinse mouth. Product presents an aspiration hazard. DO NOT INDUCE VOMITING.

If inhaled: Remove person to fresh air and keep comfortable for breathing. Call a poison center, doctor, physician or other competent medical authority if you feel unwell.

If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. A mild soap may be used to wash skin. Wash contaminated clothing before reuse. If skin irritation or rash occurs: Get medical advice or attention.

PERSONAL PROTECTION Security equipment



WHMIS



IMPORTANT: Before using **PENSOLV K4HP**, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).



CARLSTADT

700 Gotham Parkway
Carlstadt, NJ 07072
Tel.: 201-567-3000
Toll free: 1-800-631-1652

MONTREAL

10,900 Secant Street
Anjou, QC H1J 1S5
Tel.: 514-355-4660
Toll free: 1-800-361-8927

EDMONTON

11411-160 Street
Edmonton, Alberta T5M 3T7
Tel.: 780-454-3919
Toll free: 1-866-454-3919

United States
www.penetone.com

Canada
www.westpenetone.com