

PULP AND PAPER



Pensolv L115C is a solvent developed especially for paper mill wire and felt cleaning. Scientifically balanced, **Pensolv L115C** is highly effective in removing a wide spectrum of paper mill soils such as pitch, latex, resins and adhesives. It is designed for use in either continuous cleaning applications or batch cleaning for the removal of "stickies."

FEATURES AND BENEFITS

- Safe on all dewatering equipment
- Contains no phenols, chlorinated or aromatic solvents
- Mild odor
- Ready to use - no mixing required
- Removes all types of "stickies"
- Extends wire and felt life
- Reduces paperwork - no SARA Title III ingredients
- Excellent on all machine clothing: wires, wet felts, dryer fabric
- Improves sheet quality

Use procedures

While the machine is running, pump **Pensolv L115C** from the holding tank and shower onto the wire or felt using a spray bar.

Pensolv L115C can also be applied manually using a hand-held sprayer. Apply coarse spray directly to wire or felt under low pressure.

Concentration

Pensolv L115C is to be used full strength.

Note

Pretest on parts to be cleaned before use.

PENSOLV L115C

"STICKIES" REMOVAL SOLVENT

PHYSICAL PROPERTIES

Appearance	Clear liquid
Odor	Mild citrus
pH	Not applicable
Freezing Point	Less than 0°F
Boiling Point	About 400°F
Flash Point (TCC)	115°F
Relative Density	0.79
Auto-Ignition Temperature	Not determined
Water Solubility	Insoluble
Viscosity	Less than 5 CP at room temperature

INCOMPATIBILITY

Strong oxidizing agents.

WAREHOUSING PRECAUTIONS

Store in a well-ventilated place. Keep container tightly closed. Keep cool. Store locked up. Do not store near heat, sparks, open flame, or other ignition sources. Do not store in direct sunlight. Avoid storing above 120°F (49°C).

AVAILABLE SIZES

55 gallon Drum

FIRST AID MEASURES

If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists or develops: Get medical advice or attention. Penetone recommends that after any eye exposure a physician be seen immediately.

If swallowed: Immediately call a poison center, doctor, physician or other competent medical authority. Rinse mouth. Product presents an aspiration hazard. DO NOT INDUCE VOMITING.

If inhaled: Remove person to fresh air and keep comfortable for breathing. Call a poison center, doctor, physician or other competent medical authority if you feel unwell.

If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. A mild soap may be used to wash skin. Wash contaminated clothing before reuse. If skin irritation or rash occurs: Get medical advice or attention.

PERSONAL PROTECTION Security equipment



WHMIS



IMPORTANT: Before using **PENSOLV L115C**, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).



CLIFTON

125 Kingsland Avenue
Clifton, NJ 07014
Tel.: 201-567-3000
Toll free: 1-800-631-1652

MONTREAL

10,900 Secant Street
Anjou, QC H1J 1S5
Tel.: 514-355-4660
Toll free: 1-800-361-8927

EDMONTON

11411-160 Street
Edmonton, Alberta T5M 3T7
Tel.: 780-454-3919
Toll free: 1-866-454-3919

United States
www.penetone.com

Canada
www.westpenetone.com