

GENERAL USE



Pensolv L1042 Solvent Cleaner was formulated as a more user friendly replacement for kerosene and mineral spirits. It can be used in large quantities without generating excessive odors.

The high flashpoint and excellent solvency make **Pensolv L1042** the ideal cleaning solvent for maintenance parts. It can be applied manually in a conventional parts washer or enclosed spray cabinet.

Typical uses include: Wipe down of precision equipment, removal of calender stack residue, roller bearings degreasing, plastic mold cleaning, parts washing and general degreasing.

FEATURES AND BENEFITS

- Free of chlorinates
- Low vapor pressure
- High dielectric voltage
- Excellent cleaning
- Residue free after drying
- Workshop is odor free
- Non-hazardous flashpoint
- Safer for the user than most solvent cleaners
- Safe for use on electric motors
- Safe for use on all metals

DIRECTIONS FOR USE

Use procedure

Immersion tank

Immerse and agitate parts for five to ten minutes in ambient temperature solvent. Allow to air dry or blow dry to accelerate. Brush if needed.

Spray booth

Spray by non-atomizing coarse spray at fifteen to fifty PSI onto parts. Cleaning chamber should be sealed. Blow surface dry or allow to air dry.

PENSOLV L1042

MULTIPURPOSE SOLVENT CLEANER

PHYSICAL PROPERTIES

Appearance	Clear liquid
Odor	Mild hydrocarbon
pH	Not applicable
Freezing Point	About -72°F
Boiling Point	370-410°F
Flash Point (TCC)	145°F
Relative Density	0.78
Auto-Ignition Temperature	About 440°F
Water Solubility	None
Viscosity	1 centistoke at room temperature

INCOMPATIBILITY

Strong oxidizing agents.

WAREHOUSING PRECAUTIONS

Store in a well-ventilated place. Keep container tightly closed. Open slowly in order to control possible pressure release. Keep cool. Store locked up. Do not store near heat, sparks, open flame, or other ignition sources. Do not store in direct sunlight. Avoid storing above 120°F (49°C).

APPROVALS

P-D-680B

A-A-59601E

MIL-PRF-680C Ty II

AVAILABLE SIZES

6 gallon Pail

55 gallon Drum

FIRST AID MEASURES

If in eyes: Rinse cautiously with water for several minutes. If contact lenses present, remove them if easy to do. Continue rinsing for several minutes. If eye irritation persists: Get medical advice or attention. Penetone recommends that after any eye exposure and initial treatment a physician be seen immediately.

If swallowed: Immediately call a poison center, doctor, physician or other competent medical authority. Product presents an aspiration hazard. **DO NOT INDUCE VOMITING.**

If inhaled: Remove person to fresh air and keep comfortable for breathing. Call a poison center, doctor, physician or other competent medical authority if you feel unwell.

If on skin: Wash with plenty of water or a mild soap. Take off contaminated clothing and wash it before reuse. If skin irritation occurs: Get medical advice or attention.

PERSONAL PROTECTION Security equipment



WHMIS



IMPORTANT: Before using **PENSOLV L1042**, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).



CLIFTON

125 Kingsland Avenue
Clifton, NJ 07014
Tel.: 201-567-3000
Toll free: 1-800-631-1652

MONTREAL

10,900 Secant Street
Anjou, QC H1J 1S5
Tel.: 514-355-4660
Toll free: 1-800-361-8927

EDMONTON

11411-160 Street
Edmonton, Alberta T5M 3T7
Tel.: 780-454-3919
Toll free: 1-866-454-3919

United States
www.penetone.com

Canada
www.westpenetone.com