

PENETONE® CFW4 Low Foaming Caustic Felt Wash

PULP AND PAPER



Penetone CFW4 has been specifically formulated for paper machine felt and wire cleaning. Its detergents promote rapid penetration, removal and rinsing of deposits such as resin, dye, size pigments, slime, clay, starch and fibers. **Penetone CFW4** is particularly effective when used for continuous felt and wire cleaning, minimizing machine downtime.

FEATURES AND BENEFITS

- Concentrated caustic detergent
- Safe on all dewatering equipment
- Excellent for continuous or batch cleaning
- Economical
- Rapidly penetrates and rinses clean
- Cleans on the fly minimizes machine downtime
- Extends felt life



Penetone CFW4 may be used for general cleaning operations by manual, soak, circulation or pressure washing techniques.

Concentration

Dilute one part product with 10-200 parts of water, depending on the degree of soiling.

Typical use concentrations:

- Continuous cleaning 300-800 ppm
- Batch washing 1-5% by volume

PENETONE® CFW4

LOW FOAMING CAUSTIC FELT WASH

PHYSICAL PROPERTIES

Appearance	Light yellow liquid
Odor	Mild
рН	>13
Freezing Point	About 25°F
Boiling Point	About 212°F
Flash Point (TCC)	Not applicable
Relative Density	1.23
Auto-Ignition Temperature	Not applicable
Water Solubility	Complete
Viscosity	Not determined

INCOMPATIBILITY

Strong acids. Soft metals.

WAREHOUSING PRECAUTIONS

Store locked up. Store in corrosive resistant container. Plastic is recommended. Keep container tightly closed when not in use. Do not store in direct sunlight. Avoid storing above 120°F (49°C).

AVAILABLE SIZES

5 gallon Pail

55 gallon Drum

FIRST AID MEASURES

If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing, Immediately call a poison center, doctor, physician or other competent medical authority for medical advice. Penetone recommends that after any eye exposure a physician be seen immediately.

If swallowed: Rinse mouth. DO NOT INDUCE VOMITING. Immediately call a poison center, doctor, physician or other competent medical authority for medical advice.

If inhaled: Remove person to fresh air and keep comfortable for breathing. Immediately call a local Poison Control Center, physician, or other competent medical authority for medical advice.

If on skin (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. A mild soap may be used to wash skin. Wash contaminated clothing before reuse. Immediately call a local Poison Control Center, doctor, physician or other competent medical authority for medical advice.

IMPORTANT: Before using PENETONE CFW4, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).





CLIFTON

125 Kingsland Avenue Clifton, NI 07014 Tel.: 201-567-3000

MONTREAL

10,900 Secant Street Anjou, QC H1J 1S5 Tel.: 514-355-4660 Toll free: 1-800-631-1652 Toll free: 1-800-361-8927

FDMONTON

11411-160 Street Edmonton, Alberta T5M 3T7 Tel.: 780-454-3919 Toll free: 1-866-454-3919

United States www.penetone.com

www.westpenetone.com