

## GENERAL USE



Based upon proven “tamed-iodine” technology, **Wescodyne Plus** is an improved version of our traditional Wescodyne reformulated to meet current disinfection requirements in hospitals, food handling plants, and other facilities which need to control the spread of infectious diseases.

**Wescodyne Plus** contains a mixture of nonionic wetting agents complexed with elemental iodine which provides bactericidal activity. **Wescodyne Plus** is not affected by water hardness up to 400 ppm CaCO<sub>3</sub>. It also works well at low temperatures.

## FEATURES AND BENEFITS

- Broad spectrum iodophor
  - virucide
  - bactericide
  - fungicide
  - deodorizer
  - meets OSHA's bloodborne pathogens requirement
- One-step cleaner-disinfectant
- No-rinse sanitizer
- Built In color indicator

## DIRECTIONS FOR USE

### Use procedures

The color of a **Wescodyne Plus** solution is proportional to the titratable iodine concentration. Prepare a fresh solution daily, or when there is a noticeable change in its rich amber color, or more often if the solution becomes diluted or soiled.

### One-step cleaning and disinfecting

This product may be used to clean and disinfect operating areas, patient rooms, floors, walls, countertops, rest rooms, shower areas, refuse containers, bed frames, morgues, laboratories, cafeterias, commercial freezers, animal rooms, cages and other hard, non-porous surfaces.

Before applying disinfecting solution, food products and packaging materials must be removed from the room or carefully protected. Remove heavy soil deposits before applying the disinfecting solution. Using a solution of 3 ounces **Wescodyne Plus** per 5 gallons of warm water (68°F, 20°C or warmer), immerse objects in disinfecting solution, or apply solution with a mop, sponge or cloth. Where appropriate, use a mechanical sprayer to produce coarse spray. Allow a 10 minute contact time with disinfecting solution. All food contact surfaces must be rinsed with potable water before reuse. Floors, walls and other non-food contact surfaces do not require rinsing before reuse

See product label for complete use directions.

# WESCODYNE® PLUS

## CONCENTRATED BROAD SPECTRUM IODOPHOR

### PHYSICAL PROPERTIES

|                           |                                |
|---------------------------|--------------------------------|
| Appearance                | Dark red-brown viscous liquid  |
| Odor                      | Iodine                         |
| pH                        | <1                             |
| Freezing Point            | About 25°F                     |
| Boiling Point             | About 212°F                    |
| Flash Point (TCC)         | Not applicable                 |
| Relative Density          | 1.135                          |
| Auto-Ignition Temperature | Not determined                 |
| Water Solubility          | Complete                       |
| Viscosity                 | 150-250 CP at room temperature |

### INCOMPATIBILITY

Strong bases.

### WAREHOUSING PRECAUTIONS

Store locked up. Store in corrosive resistant container. Plastic is recommended. Keep container tightly closed when not in use.  
Do not store in direct sunlight.  
Avoid storing above 120°F (49°C).

### AVAILABLE SIZES

4 X 1 gallon Case

6 gallon Pail

50 gallon Drum

### FIRST AID MEASURES

**If in eyes:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a local Poison Control Center, doctor, physician or other competent medical authority for medical advice. Penetone recommends that after any eye exposure a physician be seen immediately.

**If swallowed:** Rinse mouth. DO NOT INDUCE VOMITING. Immediately call a poison center, doctor, physician or other competent medical authority for medical advice.

**If inhaled:** Remove person to fresh air and keep comfortable for breathing. Immediately call a local Poison Control Center, physician, or other competent medical authority for medical advice.

**If on skin (or hair):** Take off immediately all contaminated clothing. Rinse skin with water or shower. A mild soap may be used to wash skin. Wash contaminated clothing before reuse. Immediately call a local Poison Control Center, doctor, physician or other competent medical authority for medical advice.

### PERSONAL PROTECTION Security equipment



WHMIS



**IMPORTANT:** Before using **WESCODYNE PLUS**, always be sure to read and follow precautions and directions for use appearing on the product container label and on the safety data sheet (S.D.S).



#### CLIFTON

125 Kingsland Avenue  
Clifton, NJ 07014  
Tel.: 201-567-3000  
Toll free: 1-800-631-1652

#### MONTREAL

10,900 Secant Street  
Anjou, QC H1J 1S5  
Tel.: 514-355-4660  
Toll free: 1-800-361-8927

#### EDMONTON

11411-160 Street  
Edmonton, Alberta T5M 3T7  
Tel.: 780-454-3919  
Toll free: 1-866-454-3919

United States  
[www.penetone.com](http://www.penetone.com)

Canada  
[www.westpenetone.com](http://www.westpenetone.com)